

# DRIP LINE FITTINGS

# 420BV-06-LS Dripline x Oval Hose Connector with Valve 1-49 Pcs ..... \$ 1.50 50+ Pcs ..... \$ 1.30 FTV5-LF Dripline x Layflat Connector w/ Valve Use 16MM Layflat Punch Tool



# **YDC**





Drip line Tee

\$1.30

### **MA-06-LS**



Drip line x 1/2" MPT Connector \$0.40


#### DRIP LINE END PLUG



#FTA5-END 1-49 Pcs ..... \$0.55 50+ Pcs ..... \$0.45

#### OVAL HOSE GOOF PLUG





Punch hole in Oval Hose with #FP-420 and snap tubing adapter in place.

**SG400\*** .......... \$8.50 \*Comes w/ a 15, 30 or 60 PSI gauge

#### LAYFLAT TOOL



**LFP-LS-16**......16 MM.... Red..... \$ 56.00 **LFP-LS-19**......19 MM.... Blue.... \$ 59.00

#### FLEX RISER



1/2" x 6" flex riser for use with buried header line & drip tape.

**12500407** ..... \$ 1.10

400B-06-LSO

DRIP TAPE

Installation Layout

#### CPT-06-LSO



Drip line Repair Coupling 1-49 Pcs ..... \$ 0.50 50+ Pcs ..... \$ 0.30

#### FHC-06-LSO



Drip line x Layflat Connector Use 19MM Layflat Punch Tool 1-49 Pcs ..... \$ 1.10 50+ Pcs ..... \$ 0.95

#### FTV-500



Drip line Coupler with Valve 1-49 Pcs .....\$ 1.50


50+ Pcs .....\$ 1.30

# FHS-06-LSO



Drip line x Garden Hose Connector \$ 1.50

#### CSP-06-LS



#### FCH-06-LSO



Drip Line Self-Flush End \$1.50

#### LAYFLAT GOOF PLUG



Large Layflat Goof Plug

FHC-06-PLUG....... \$ 1.65

#### SNAP ON GAUGE



Punch hole in Oval Hose with #FP-420 and snap gauge in place


**SN400\*** ..... \$ 7.00 \*Comes w/ a 15, 30 or 60 PSI gauge

#### **OVAL HOSE TOOL**

Punch tool for 400B-06-LS installation.

**DP400S**......\$ 25.00

#### 400B-06-LSO



Also for 3/8" Supply Tubing 1-49 Pcs ..... \$ 0.50 50+ Pcs ..... \$ 0.40

#### FTA5-LF



Drip line x Layflat Connector Use 16MM Layflat Punch Tool 1-49 Pcs ..... \$ 0.95 50+ Pcs ..... \$ 0.80


#### ELL-06-LSO



Drip line Elbow


\$1.75

#### 420-50



#### DRIP LINE END SLEEVE

Plug your row by folding drip tape several times



## **G**ROMMETS FOR **P**VC **P**IPE



**400GRO**....9/16" Hole .......400 Barb ... \$ 0.50 Minimum 1½" PVC

**700GRO**.... 13/16" Hole......700 Barb ... \$ 0.70

#### LAYFLAT GAUGE



Punch hole in Layflat with Layflat Tool and insert gauge in place

**LF400**.....\$ 7.50

# Installation Tool



T-handle hex tool for layflat fitting installation. (16MM) **LF-INST-T**.....\$6.00

(19MM) LF-INST-J ..... \$6.00

### **OVAL HOSE TOOL**



Punch tool for Oval Hose fitting installation.

FP-420 .....\$ 13.00

# **DRIP LINE FITTINGS**

#### 700B-09-LS



Drip line x Oval Hose Connector \$0.80

#### FTV7-LF



Drip line x Layflat connector with valve

#### FTV7-400B



\$2.00



Drip line x Oval Hose

Connector w/ Valve \$1.75



Drip line x drip line connector with \$1.75

#### CPT-09-LS



Drip line Repair Coupling 1-49 Pcs ..... \$ 0.90 50+ Pcs ..... \$ 0.80

# FTA7-LF




Drip line x Layflat connector \$1.50

## FTA7-END



1-49 Pcs ..... \$ 0.75 50+ Pcs ..... \$ 0.65

## **DP700**





\*Best setup for most

vegetable crops.