


Assembly Instructions


MODEL 2470
RAISED BED PLASTIC MULCH LAYER

STEP 1Unpackage & Count Parts/Assemblies



Standard Parts Shipped with Model 2470:






Cover Disk w/ Dirt Shield Set

STEP 2

Installing Disks & Press Wheels

- 1 Bolt disk assemblies to back of machine using pre-installed bolts.
- 2 Install chains (chains support disks when machine is raised).
- 3 Install press wheels and secure with pre-installed cotter pin.
- 4 Slide spring rod through bracket on disk assembly and secure with pre-installed lynch pin.


See Operating Manual for Adjustments



STEP 3

INSTALLING DRIP TAPE

See Operating Manuel for Adjustments




Remove plate with locking clamp(A). Slide drip roll onto rod, press plate(A) tight against roll and tighten tee-handle on clamp. Feed drip tape through swing arm guide and stationary guide(B) (See Sketch) then into drip line down pipe(C).

Note; Turn drip emitters up toward plastic for less clogging, and make sure drip roll is compressed firmly between plates for positive braking effect.

STEP 4 INSTALLING PLASTIC

See Operating Manuel for Adjustments

Place plastic rolls on top of rollers(**A**). Pull end of plastic down in between rollers and underneath bottom roller(**B**). Secure plastic and drip tape at end of row. Only feed from one roll at a time.



WATER TANK



The Mini Layer has a 50 gallon water tank for weight to make a firm bed. Add as much water (weight) as possible without exceeding the tractor's lifting capacity. The 3-point top link can be lengthened if pulling too much soil.

STEP 5

TRACTOR HOOK-UP

The Model 2470 has Category I and II lift pins(**A**) on a 3-point hitch. Hook up 3-point top link to top of A-frame(**B**) and adjust top link to level machine. Use top hole for higher lift. See Operators Manual for more details on adjusting top link according to soil conditions.



~2021 Edition~



Rain-Flo Irrigation (717) 445-3000